



More information on the website  
[radwag.com/us/info,w1,10R](https://radwag.com/us/info,w1,10R)

## PT0022 Cable



The drawings, photos and graphics used are for illustrative purposes only.

### Overview

RS 232 cable for connecting a balance/scale (PUE C/41H, PUE HY10, PUE 5 indicator) to a ZEBRA printer.

Standard cable length: 2m

Customized cable length (extra charge): 5 or 10m

Compatible with:

- Scales operated by means of PUE C41H terminal
- Scales operated by means of PUE 5.15 (5.19) terminal
- Scales operated by means of PUE HY10 terminal
- PUE C41H terminal
- PUE 5.15 (5.19) terminal
- PUE HY10 terminal

### Compatible with

HX7 H Multifunctional Scale  
HX7.4N H Multifunctional Stainless Steel Ramp Scale  
HX7.4C Multifunctional Platform Scale  
HX7 HR Multifunctional Scale

HX7.4 H/Z Multifunctional Stainless Steel Platform Scale, pit version  
HX7.4 H Multifunctional Stainless Steel Platform Scale  
HX7.4P2 Multifunctional Beam Scales  
HY10.H scales for PGC

HY10.HRP.H High Resolution Scale  
HX7.4P2 H Multifunctional Stainless Steel Beam Scales  
TMX H Stainless steel Multifunctional Scale  
TMX Multifunctional Scale  
HX7.4N H.LD Multifunctional Stainless Steel Ramp Scale  
DWT/RC/HYF Checkweighers  
HX7.4P H Multifunctional Stainless Steel Pallet Scales  
HY10 Multifunctional Scale  
HY10 H Stainless Steel Multifunctional Scale  
HY10.HRP High Resolution Scale  
HX7 Multifunctional Scale

PUE C32 Weighing Terminal  
PUE HX7 Weighing Terminal  
PUE 5 Weighing Terminal  
DWR/H Checkweighers  
Label Printers  
DWM H2 Checkweighers  
HX7.4P Multifunctional pallet scales  
DWM Checkweighers  
DWT/RC/HY Checkweighers  
Roller Scales