



More information on the website  
[radwag.com/us/info,w1,4LG](http://radwag.com/us/info,w1,4LG)

## PT0287 Cable

WX-013-0226



The drawings, photos and graphics used are for illustrative purposes only.

### Overview

The PT0287 cable is an RS232 cable that connects the RTP-RU80 printer to scales equipped with an RS232 connector (DB9 M). These are the WTC and WLC scales and scales featuring the PUE C315, PUE C32, and PUE 7.1 indicators and terminals.

The standard length of the PT0232 cable is 1.7 m.

### Compatible with (Additional Fee)

WPY Multifunctional Scale  
C32 Multifunctional Scale  
C315 Platform scale  
WLY Scales for PGC  
C315.D Baby scale  
WLC Precision Balance  
C315.4P2 Beam Scales  
WLC X7 Precision balance  
PUE 7.1.HRP High Resolution Scale  
C315.4 Platform Scale  
C32.PM Precision Balance  
C315.0 Personal scale

WTC Precision Balance  
C315.OW Personal scale  
WLY Precision Balance  
WLC C/2 Precision balance  
PUE C32 Weighing Terminal  
PUE 7.1 Weighing Terminal  
Postal scales for packages  
PUE C315 Terminal  
H315 H Waterproof Platform Scale  
C315.4B Bed scale  
C315.K Chair scale  
C315.8B Ramps bed scale

