



More information on the website  
[radwag.com/es/info,w1,FOT](http://radwag.com/es/info,w1,FOT)

## HUB USB 3.0



The drawings, photos and graphics used are for illustrative purposes only.

## Descripción

The HUB is powered via the USB and does not require driver installation. Simply connect the USB cable to your device and computer and start working. The HUB features surge protection in the event of a short circuit on peripheral devices.

The HUB is equipped with 4 USB 3.0 Plug & Play ports. They make it possible to connect enough necessary devices. The USB 3.0 ports are particularly important for optimum data transfer from a USB 3.0 flash drive.



## Trabaja con

Microbalanza XA 5Y.M.A.P  
Bascula multifuncionale WPY  
Microbalanza para calibración de pipetas MYA 5Y.P  
Analizador de HumedadMA 5Y  
Balanza de precisión 5Y.PM

Analizador de HumedadMA 5Y.IC  
Balanza analítica AS 5Y  
Balanza de precisión CY10  
Balanza analítica para filtros XA 5Y.F  
Balanza de precisión WLY

Microbalanza para filtros MYA 5Y.F  
Balanzas WLY para CCE  
Microbalanza XA 5Y.M.A  
Terminal de pesaje PUE CY10  
Bascula multifuncionale CY10  
Balanza de alta resolucion PUE 7.1.HRP  
Dispositivo automático para la calibración de pipetas multicanal  
Balanzas WPY para CCE  
Balanza analítica XA 5Y.A

Microbalanza MYA 5Y  
Microbalanza MYA 5Y  
Balanza analítica XA 5Y  
Terminal de pesaje PUE 7.1  
Balanza de precisión PS 5Y  
Microbalanza XA 5Y.M  
Bascula de rampa impermeable H315  
Microbalanza XA 5Y.M.A.S