



More information on the website  
[radwag.com/en/info,w1,MLB](http://radwag.com/en/info,w1,MLB)

## Tare and Print External Buttons



The drawings, photos and graphics used are for illustrative purposes only.

### Overview

Buttons for remote control of TARE and PRINT functions. The buttons are enclosed in a plastic housing, the unit features 1.5 m cable. PT0021 - (PUE C41H ) PT0213 - (PUE 5.15, PUE 5.19, PUE HY10, PUEHX7) PT0188 - (PUE 7.1)

\* Connects with an indicator equipped with 4in/out module on connectors.

### Compatible with

HX7 H Stainless steel Multifunctional Scale  
 HX7.4N H Multifunctional Stainless Steel Ramp Scale  
 HX7.4C Multifunctional Platform Scale  
 HX7 HR Multifunctional Scale  
 WPY Multifunctional Scale  
 C32 Multifunctional Scale  
 HY10.HRP.H Stainless steel High Resolution Scale  
 HX7.4P2 H Multifunctional Stainless Steel Beam Scales  
 WLY Scales for PGC  
 HX7.4N H.LD Multifunctional Stainless Steel Ramp Scale  
 DWT/RC/HYF Checkweighers  
 HX7.4P H Multifunctional Stainless Steel Pallet Scales  
 HY10 Multifunctional Scale

HY10.HRP High Resolution Scale  
 HX7 Multifunctional Scale  
 HX7.4 H/Z Multifunctional Stainless Steel Platform Scale, pit version  
 WPY Scales for PGC  
 HX7.4 H Multifunctional Stainless Steel Platform Scale  
 HX7.4P2 Multifunctional Beam Scales  
 HY10.H Scales for PGC  
 WLY Precision Balance  
 PUE C32 Weighing Terminal  
 PUE 7.1 Weighing Terminal  
 PUE HX7 Weighing Terminal  
 DWM H2 Checkweighers  
 HX7.4P Multifunctional pallet scales

