



H315.4I.2000.S1 Livestock Scale, H315.4I.2000.S2 Livestock Scale, H315.4I.2000.S3 Livestock Scale

More information on the website
radwag.com/en/info,w1,9HA



H315.4I.2000.S1 Livestock Scale



H315.4I.2000.S2 Livestock Scale
H315.4I.2000.S3 Livestock Scale

The drawings, photos and graphics used are for illustrative purposes only.

Functions



Plus/Minus Control



Percent Weighing



Totalizing



Parts counting



Internal battery



Peak hold



Newton unit
measurement



Animal weighing

Datasheet

	H315.4I.2000.S1 Livestock Scale	H315.4I.2000.S2 Livestock Scale	H315.4I.2000.S3 Livestock Scale
Metrological parameters			
Maximum capacity [Max]	2000 kg	2000 kg	2000 kg
Minimum load	20 kg	20 kg	20 kg
Readability [d]	1 kg	1 kg	1 kg
Tare range	-2000 kg	-2000 kg	-2000 kg
OIML Class	III	III	III
Physical parameters			
Display	LCD (backlit)	LCD (backlit)	LCD (backlit)
Weighing pan dimensions	1x2 m	1x2 m	1x2,5 m
Scale mass with indicator	290 kg		
Barriers height	1,1 m	1,8 m	1,8 m
Construction			
Protection class	IP 67 construction, IP 68 (1h max)/69 indicator	IP 67 construction, IP 68 (1h max)/69 indicator	IP 67 construction, IP 68 (1h max)/69 indicator
Communication interface			
Communication interface	RS232, USB	RS232, USB	RS232, USB
Optional interfaces	RS232 or RS485 or 4IN/4OUT or Ethernet or analog output 4-20 mA	RS232 or RS485 or 4IN/4OUT or Ethernet or analog output 4-20 mA	RS232 or RS485 or 4IN/4OUT or Ethernet or analog output 4-20 mA
Electrical parameters			
Power supply	100 – 240 V AC 50/60 Hz	100 – 240 V AC 50/60 Hz	100 – 240 V AC 50/60 Hz
Optional power supply	internal rechargeable battery	internal rechargeable battery	internal rechargeable battery
Operation time on batteries	max 7h	max 7h	max 7h
Environmental conditions			
Operating temperature	-10 ÷ +40 °C	-10 ÷ +40 °C	-10 ÷ +40 °C
Relative humidity	10% ÷ 85% RH no condensation	10% ÷ 85% RH no condensation	10% ÷ 85% RH no condensation



Extra payment for verification



Accessories

RS 232 cables (scale - printer)
Displays
RS 232 cables (scale - Ethernet)
RS 232, RS 485 cables
RS 232 – Ethernet Converter
USB adapter

Receipt Printer
USB cable (scale - printer)
Stands, wall mounting kits and mounting brackets
RS 232 – USB Converter
RS 232, RS 485 cables

Software

RAD-KEY
R-LAB

R Panel
Scales Editor 2.1

Device dimensions

H315.4I.2000.S1 Livestock Scale, H315.4I.2000.S2 Livestock Scale, H315.4I.2000.S3 Livestock Scale

