



More information on the website  
[radwag.com/us/info,w1,PES](http://radwag.com/us/info,w1,PES)

# PUE H315 Weighing Terminal



The drawings, photos and graphics used are for illustrative purposes only.

## Functions

 Plus/Minus Control


 Percent Weighing

 Totalizing

 Parts counting

 Internal battery

 Peak hold

 Newton unit measurement

 GLP Procedures

 Animal weighing

 ALIBI Memory

## Datasheet

OIML Class	III
Maximum quantity of divisions from converter	838 860 ×10
Maximum quantity of verification units	6000 e
Minimum volatge per verification unit	0,4 μV
Maximum voltage per verification unit	3,25 μV
Minimum load cell impedance	50 Ω
Maximum load cell impedance	1200 Ω
Load cell excitation voltage	5V DC

Maximum increase of signal	39 mV
Connection of load cells	4 or 6 wires + shield
<b>Physical parameters</b>	
Display	LCD (backlit)
Device dimensions	208×145×80 mm
Packaging dimensions	300×250×130 mm
Net weight	1,9 kg
Gross weight	2,2 kg
<b>Construction</b>	
Protection class	IP 66 / 67 / 69
Keypad	microswitch
Housing	Stainless steel
<b>Communication interface</b>	
Communication interface	RS232, USB
Optional interfaces	RS232 or RS485 or 4IN/4OUT or Ethernet or analog output 4-20 mA
<b>Power supply</b>	
Power supply	100 – 240 V AC 50/60 Hz
Optional power supply	internal rechargeable battery
Operation time on batteries	max 7h
<b>Operating conditions</b>	
Operating temperature	-10 – +40 °C
Storage temperature	-10 – +50 °C
Relative humidity	10% – 80% RH no condensation
Number of buttons	5
Multiple range	1 or 2 ranges
Additional LCD display	WD-4/1 (option)



## Compatible with

Waterproof stainless steel platforms  
Mild steel powder coated weighing platforms  
RS 232 cables (scale - printer)  
RS 232, RS 485 cables  
Mild steel powder coated weighing platforms  
Displays  
RS 232 cables (scale - Ethernet)  
USB adapter

Receipt Printer  
Additional modules  
USB cable (scale - printer)  
Stands, wall mounting kits and mounting brackets  
RS 232 – USB Converter  
RS 232, RS 485 cables  
RS 232 – RS 485 Converter

## Software

- RAD Key [WX-010-0005]
- Scale Editor - EWAG 2.1 [WX-010-0173]

- R Panel [WX-010-0187]
- RADWAG Development Studio [WX-010-0104]

# Device dimensions

